



Installation Procedures

B5.5 Passat - B5/B6/B7 Audi A4 ECS Pedal Installation Instructions

This tutorial is provided as a courtesy by ECS Tuning.

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will ECS Tuning, Incorporated or its affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.



Installation Procedures

B5.5 Passat - B5/B6/B7 Audi A4 ECS Pedal Installation Instructions

**ES#10115 Pedal Set Black
ES#10116 Pedal Set Silver**

Safety First:

Work carefully to avoid damaging wires and connectors. Avoid any test procedure that damages wire insulation or creates a short circuit, to voltage, ground, or another circuit. Failure to follow these and all other safety precautions and approved shop practices can result in costly vehicle damage and serious personal injury.

Read the instructions completely before starting! Obtain all required tools. If the installation procedures are beyond your tools and skills, contact a qualified installer for professional assistance.



B5.5 Passat - B5/B6/B7 Audi A4 ECS Pedal Installation Instructions

ES#10115 Pedal Set Black
ES#10116 Pedal Set Silver

Kit Contents

Three ECS Pedals (gas, brake, clutch)

Center punch

Attachment hardware - 9 countersunk screws and 9 locking nuts

Estimated Installation Time: 1.5 Hour

Preparation:

Park automobile in a level working area.

Put the vehicle in Park and engage the parking brake.

Installation Note: Install pedals using countersunk machine screws with locking nuts, for safety.

Tools Required:

- Phillips Head Screw Driver
- 4mm Drill Bit
- Drill
- Centering Punch
- 3mm Allen Driver
- Work Light



©2011 ECS TUNING.COM

B5.5 Passat - B5/B6/B7 Audi A4 ECS Pedal Installation Instructions

Step 1.

Remove the stock brake and clutch pedal covers.

The stock rubber covers are quite stiff. Pull hard to remove them.



Step 2.

Position the pedal cover over the clutch pedal and mark the screw holes with the spring-loaded center punch.



Step 3.

Drill the three holes marked with the center punch, using a 4 mm drill bit.



B5.5 Passat - B5/B6/B7 Audi A4 ECS Pedal Installation Instructions



Step 4.

Install the pedal cover. Use the supplied Allen-head screws with locknuts on the backside, for safety.



Step 5.

Repeat the process for the accelerator pedal.

Place the pedal cover over the pedal. Mark the location of the pedal cover screws on the pedal.

Then drill the 4 mm holes.



Step 6.

Install the ECS accelerator pedal cover. Use the supplied Allen-head screws, with locknuts on the backside, for safety.



B5.5 Passat -B5/B6/B7 Audi A4 ECS Pedal Installation Instructions



Step 7.

Position the brake pedal cover and mark the hole using the spring-loaded center punch.



Step 8.

Remove the pedal cover while you drill the screw holes. This is a tight fit; use a right angle drill.



Step 9.

Install the brake pedal cover. Use the supplied Allen-head screws with locknuts on the backside, for safety.

This completes the ECS pedal installation.

